

---

# M25S 24V motor

Instruction for adjusting bottom limit and intermediate position

**Venetian Blinds / Duette® / Pleated Blinds**

---

---

## Colophon

This bulletin remains the property of Hunter Douglas. Its contents are strictly confidential and may not be reprinted, copied, reproduced or multiplied in whatever form. It must be returned upon request by Hunter Douglas.

The information presented in this manual serves to inform our customers. The manual is based upon general information concerning constructions, material properties and operating procedures as they are known to us at the moment of publication. That is why this manual is subject to change or additions at all times. Hunter Douglas reserves the right to make any changes and/or additions deemed necessary.

Because of the afore-mentioned reasons, this assembly manual is not a manual for installation, use or maintenance of products by Hunter Douglas®. If a user of products by Hunter Douglas® has any questions or experiences any difficulties during the use and/or maintenance of such products, Hunter Douglas should be contacted.


© - 2018 – Hunter Douglas Europe BV  
® - Registered Trademark of Hunter Douglas  
Printed in the Netherlands

Publication number  
11-M-04EN-V10


Release date  
19-04-2018

---

## ADJUSTING THE BOTTOM LIMIT



## SETTING INTERMEDIATE STOP POSITION



## REMOVING INTERMEDIATE STOP POSITION

